


Replacement remote control for GBC, iSNATCH, XDOME and Jollyline decoders + main tv functions



Number of devices	1 + 1 (learning)
Controllable devices	Decoder + TV
Controls	Main functions DTT + Essential TV functions
Functions	Menu, Av
Brands	Works with all GBC, iSNATCH, XDOME and Jollyline decoders
Type of programming	Ready to use for the decoder, just insert the batteries and it's ready to use. Learning from original for TV.
Batteries	2x 1,5 V - AAA (not included)
Code stored	Does not lose memory during battery replacement



Packaging 5 x 18 x 2 cms

