Replacement remote control for SAMSUNG, LG, SONY, PHILIPS and PANASONIC TV's



Number of devices

Controllable devices SAMSUNG, LG, SONY, PHILIPS and PANASONIC TV's

Controls Controls all functions

Functions Menu, AV, Teletext, Color

Brands It works with all SAMSUNG, LG, SONY, PHILIPS and PANASONIC models

Type of programming. You only have to insert batteries and it is ready to be used.

Batteries 2x 1,5 V - AAA (not included)

Code stored Does not lose memory during battery replacement



Packaging 6 x 29 x 3 cms





