

Replacement remote control for SAMSUNG, LG, SONY, PHILIPS and PANASONIC TV's



Number of devices

1

Controllable devices

SAMSUNG, LG, SONY, PHILIPS and PANASONIC TV's

Controls

Controls all functions

Functions

Menu, AV, Teletext, Color

Brands

It works with all SAMSUNG, LG, SONY, PHILIPS and PANASONIC models

Type of programming

No need of programming. You only have to insert batteries and it is ready to be used.

Batteries

2x 1,5 V - AAA (not included)

Code stored

Does not lose memory during battery replacement



Packaging 10 x 28 x 3 cms

