

Replacement remote control for Sony TV sets with same symbology as the original one



Number of devices

1

Controllable devices

TV SONY

Controls

Controls all functions

Functions

Menu, AV, Teletext, Color

Brands

Compatible with all Sony models

Type of programming

No need of programming. You only have to insert batteries and it is ready to be used.

Batteries

2x 1,5 V - AAA (not included)

Code stored

Does not lose memory during battery replacement



Packaging 6 x 29 x 3 cms



Quantity in  
master carton  
50 pz.