

Replacement remote control for TELEFUNKEN, VESTEL and BEKO TV's with symbology as the original one



Number of devices

1

Controllable devices

TELEFUNKEN, VESTEL and BEKO TV's

Controls

Controls all functions

Functions

Menu, AV, Teletext, Color

Brands

It works with all TELEFUNKEN, VESTEL and BEKO models

Type of programming

No need of programming. You only have to insert batteries and it is ready to be used.

Batteries

2x 1,5 V - AAA (not included)

Code stored

Does not lose memory during battery replacement



Packaging 6 x 29 x 3 cms



Quantity in
master carton
50 pz.