## REPLACEMENT FOR PANASONIC




## Number of devices Controllable devices Controls Functions Brands Type of programming Batteries Code stored

## 1

TV PANASONIC
Controls all functions
Menu, AV, Teletext, Color
Compatible with all Panasonic models
No need of programming. You only have to insert batteries and it is ready to be used.
2x 1,5 V - AAA (not included)
Does not lose memory during battery replacement











Via delle Valli, snc 04011, Aprilia (LT) www.jollyline.it



